



TECHNISCHE
UNIVERSITÄT
DRESDEN

Faculty of Computer Science Institute of Computer Engineering, Chair of VLSI Design, Diagnostics & Architecture

THE PS/2 PROTOCOL

Dr. Thomas B. Preußner

thomas.preusser@tu-dresden.de

Dresden, July 7, 2014




Goals of this Lecture


- Describe the communication across a PS/2 bus.
- Enable the design of a PS/2 controller.

Bit-Level Protocol

- synchronous serial protocol on open-drain bus,
- PS/2 plug (mini DIN)



1. Clock (Open Drain)
2. Ground
3. Data (Open Drain)
4. %
5. Vcc (5V)
6. %




Characteristics


- bit-serial transmission of bytes, LSB first,
- odd parity for ensuring data integrity,
- framing by start, stop and ack bits,
- clock always defined by the device ($f \sim 10 \dots 17 \text{ kHz}$),
- direction of communication defined by the host, and
- host reads or writes data bits at falling clock edge.

Timing

Device → Host:



Host → Device:



Initiation by host on clock line (about 1.5 bit widths).

blue Device
red Host

00 AT Keyboard: Overview

Duties of the Keyboard:

- Transmission of scan and release codes,
- debouncing of keys,
- repetition of scan codes as long as a key is held, and
- display of status LEDs.

Duties of the Host:

- Interpretation of the scan codes,
- management of the *lock* key states, and
- control of the status LEDs.



Commands

Host → Keyboard:

ED	Setting the Status LEDs <i>followed by byte containing a bitmask</i>
EE	Echo Request
F4	Keyboard Enable
F5	Keyboard Disable
FE	Resend: repeat most recent byte
FF	Keyboard Reset

Keyboard → Host:

EE	Echo Reply
FA	Acknowledge
FE	Resend: repeat most recent byte
FF	Error

Basic PS/2 Mouse

- 2× 9-bit, 2's-complement counter with overflow flag (x- and y-movements)
- 3× button states (left, right, center)
 - transmitted in 3-byte packets:

Overflow		Sign		1	Keys		
Y	X	Y	X		center	right	left
X-Movement							
Y-Movement							

counters are reset by transmission

Operation Modes

- **Reset Mode:**

1. executes BAT (Basic Assurance Test) transmitting result to host,
2. sets default values: Sampling Rate: 100 Hz
Resolution : 4 mm^{-1}

- **Stream Mode:**

Unsolicited state updates are sent to the host,
at most with the configured sampling rate (10, 20, 40, 60, 80, 100, 200 Hz).

- **Remote Mode:**

State updates must be requested (0xEB) individually by the host.

- **Wrap Mode:**

Mouse echoes all data sent to it.

Only 0xEC "Reset Wrap Mode" und 0xFF "Reset" are interpreted with their command semantics.

Mouse Commands

E8	Set Resolution
E9	Query Status
EA	Activate Stream Mode
EB	Request a State Update
EC	Leave Wrap Mode
EE	Enter Wrap Mode
F0	Enter Remote Mode
F2	Query Device ID
F3	Set Sampling Rate
F4	Activate Data Transmissions
F5	Deactivate Data Transmissions
F6	Set Default Values
FE	Resend
FF	Reset

Microsoft IntelliMouse Extensions

The command sequence

1. Set Sample Rate to 200 Hz
2. Set Sample Rate to 100 Hz
3. Set Sample Rate to 80 Hz

activates the extra functions of scroll mice.

→ The status packet is extended by one byte containing the incremental movement of the scroll wheel. (range: $-8 \dots 7$)

The command sequence

1. Set Sample Rate to 200 Hz
2. Set Sample Rate to 200 Hz
3. Set Sample Rate to 80 Hz

activates two more buttons (if available).

Additional data byte:

0	0	Keys		Z-Movement
		5.	4.	